





Select the icon on your device to start




Turn on the Bluetooth connection



Actual setup loading from the DSP unit




Main page appearing and level control



Dropdown menu with APP version information




Advanced settings – select the channel to setup




Mixer – select the input signal for the channels




Link pairs of channels for identical settings




Equalizer – adjust the level of the EQ bands




Slide to change from band 1-5 to band 6-10



Slide to change from band 1-5 to band 6-10



Select a band to adjust the frequency



Select a band to adjust the Q of the filter



Time Delay – adjust the delay for each channel



Select distance in cm instead of time elapse




...or inches if required



Crossover – set the HP and LP filter character



Crossover – set the HP and LP filter slope




Crossover – set the HP and LP filter frequency



Memory – save your setting to the DSP unit



Memory – load presets from the DSP unit



Memory – delete presets from the DSP unit